

Mégane

N.T. 3156A

XA0X

ENCRYPTED KEY TRANSPONDER ENGINE IMMOBILISER

For the sections not covered in this Technical Note, refer to Workshop Manual MR 312

Cancels and replaces Technical Notes 3060A, 3080E and 3088A

77 11 202 159

DECEMBER 1998

Edition Anglaise

The repair methods given by the manufacturer in this document are based on the technical specifications current when it was prepared.

The methods may be modified as a result of changes by the manufacturer in the production of the various component units and accessories from which his vehicles are constructed".

All copyrights reserved by Renault.

Copying or translating, in part or in full, of this document or use of the service part reference numbering system is forbidden without the prior written authority of RENAULT.

Contents

	Page		Page
82 ENGINE IMMOBILISER		82 ENGINE IMMOBILISER (cont)	
New features	82-1	FAULT FINDING	
General	82-2	<i>Coded key with PLIP</i>	
Presentation of the system	82-3	Introduction	82-22
Description of the system	82-4	XR25 fiche	82-23
Removal - refitting of the antenna / transponder ring	82-4	Representation of bargraphs	82-25
Removal - refitting of the decoder unit	82-5	Interpretation of XR25 bargraphs	82-26
Removal - refitting of the passenger compartment control unit (UCH)	82-6	Customer complaints (petrol version)	82-36
Operation	82-7	Fault charts	82-37
Replacing, reallocating or adding one or more coded key heads	82-8	Customer complaints (diesel version)	82-42
Replacing a decoder unit only	82-11	Fault charts	82-43
Replacing a UCH only	82-13	Checking conformity	82-48
Replacing the injection computer	82-16	Additional checks	82-50
Checking	82-17	<i>Coded key without PLIP</i>	
Replacing the electronic unit in the coded solenoid valve	82-17	Introduction	82-51
Decoder unit connections	82-18	XR25 fiche	82-52
Passenger compartment control unit (UCH) connections	82-19	Representation of bargraphs	82-53
Operating diagram	82-20	Interpretation of XR25 bargraphs	82-54
Components key	82-21	Customer complaints (petrol version)	82-62
		Fault charts	82-63
		Customer complaints (diesel version)	82-67
		Fault charts	82-68
		Checking conformity	82-72
		Additional checks	82-75

IMPORTANT
NEW ENGINE IMMOBILISER SYSTEM
NEW PROCEDURES

New features:

- There is no longer a security code, but a repair code allocated to the vehicle for life from the time of manufacture (there is no longer a number inscribed in the key head).
For any operation on this system, this repair code number can be obtained from the local assistance network (example : Delta Assistance for France, NVSR for the UK by fax only).
From now on, the vehicle VIN number and fabrication number will have to be provided with every code number request. This allows the operator to identify the vehicle so that the correct code is given.
- Spare keys are supplied uncoded, without numbers.
- This system can involve a maximum of four keys in conjunction with or without PLIPs.
- This system can be used with a radio frequency PLIP for locking/unlocking the doors (vehicle with UCH only). **This radio frequency PLIP (if equipped) does not affect the engine immobiliser.**

• **IMPORTANT:**

With this new system, it is not possible to replace a complete set (decoder units or UCH* and key heads) at once. These components are sold uncoded.

This is because it will not be possible to code these components when replacing them if none of them has the original vehicle code in their memory.

* Passenger Compartment Control Unit.

GENERAL

It is based on an engine immobiliser controlled by a key recognition system with a random rolling code.

A coded electronic unit (operating without a battery), independent of the operation of the PLIP (if equipped) is integrated in the head of each key for the vehicle.

When the ignition is switched on, a ring around the ignition switch interrogates and captures the code sent by the key and transmits it to the decoder unit or to the UCH* (depending on equipment).

If it recognises the code, vehicle starting will therefore be authorised.

The engine immobiliser is activated a few seconds after the key is removed from the ignition switch and is visualised by flashing of the red tell-tale light located on the instrument panel.

When a vehicle is manufactured, a code with eight characters is allocated to it so that the engine immobiliser system can be made operational.

This number will be required in after sales for:

- adding keys with or without PLIPs (maximum of four keys in total),
- "de-allocation" of one or more keys,
- replacing one or more keys,
- replacing a decoder unit or a UCH* depending on equipment.

* Passenger Compartment Control Unit


This number, which consists of eight numbers, is available from the local assistance network (Delta Assistance for France, NVSR for the UK by fax only, for example) using the vehicle's VIN and fabrication number.

NOTE:

- This system can be fitted to petrol or diesel vehicles
Petrol and direct injection diesel vehicle (example : F9Q) : the engine immobiliser function is carried out by the injection computer.
Diesel vehicle with coded solenoid valve: the engine immobiliser function is carried out by a coded solenoid valve (on the injection pump).

IMPORTANT: vehicles equipped with the **F9Q** engine have a special injection computer which will only operate if it is coded.

PRESENTATION OF THE SYSTEM



15357R1

- A Engine immobiliser key with or without PLIP
- B Engine immobiliser antenna / transponder ring
- C Decoder unit or UCH* (depending on equipment)
- D Red engine immobiliser tell-tale light
- E Injection computer (petrol or direct injection diesel)
- F Diesel coded solenoid valve (except direct injection diesel)
- G Diagnostic socket

* Passenger Compartment Control Unit (on vehicle with door locking PLIP).

** This tell-tale light is not functional on all vehicles (see Wiring Diagrams).

DESCRIPTION OF THE SYSTEM

With this system, the engine immobiliser is activated approximately **10 seconds** after the ignition is switched off (shown by flashing of the red immobiliser tell-tale light).

It consists of:

- Two special key heads (with or without PLIP) (A) fitted with a coded electronic unit allowing control of the engine immobiliser.
- An antenna / transponder ring (B), located around the ignition switch, fitted with an electronic unit which is responsible for transmitting the code from the keys to the decoder unit or the UCH (C) (depending on equipment).

NOTE : this ring is not coded.

- A decoder unit or **UCH*** (C) located under the dashboard on the driver's side.

It ensures the following functions:

- decoding of the key signal from the antenna / transponder ring,
- management of the engine immobiliser system by sending a code to the injection computer (petrol or direct injection diesel) or to the coded solenoid valve (diesel except direct injection) to authorise vehicle starting,
- control of the red immobiliser tell-tale light,
- dialogue with the fault finding tool.

NOTE: for other functions controlled by the UCH (depending on equipment), see the corresponding Technical Note.


- A red engine immobiliser tell-tale light (D) located on the instrument panel which signals:
 - activation of the engine immobiliser system,
 - non-recognition of the key,
 - a fault on the system for vehicles fitted with a coded solenoid valve (diesel).

* Passenger Compartment Control Unit.

- An injection computer (E) (petrol or direct injection diesel).
- A coded solenoid valve (F) (diesel except direct injection).
- A diagnostic socket (G) used for the repair and configuration of the system.

REMOVAL - REFITTING OF THE ANTENNA / TRANSPONDER RING

Place the steering column at its highest setting (depending on equipment) and remove the lower half cowling (three bolts).



Disconnect the ring connector.

Turn the ring a quarter turn clockwise and release it.


When refitting, ensure that the ring and the wiring are correctly positioned and clipped in place.

IMPORTANT: so that the coil wires are not damaged, do not put the ring or its connector under stress when removing or refitting the half cowling. Damage to these wires will lead to non-recognition of the key when the ignition is switched on.

REMOVAL - REFITTING OF THE DECODER UNIT (depending on equipment)


Remove:

- the fuse cover,
- part (A) by removing its two bolts,
- the mounting bolt (B) from the relay fuse unit.



Unclip the relay fuse unit from its two side supports by pushing it towards the front of the vehicle and release it from below the dashboard.

To access the decoder unit, open cover (C) by pressing on tabs (D) at the bottom of the relay fuse unit.




IMPORTANT: ensure that cover (C) is correctly in place when refitting.

REMOVAL - REFITTING OF THE PASSENGER COMPARTMENT CONTROL UNIT (UCH) (depending on equipment)

Remove:

- the fuse cover,
- part (A) by removing its two bolts,
- the mounting bolt (B) for the UCH.




Disconnect the connector located under the UCH unit.

Unclip the fuses/UCH mounting from its two side supports by pushing it towards the front of the vehicle and release it from below the dashboard.

Remove the protective plastic cover.

Disconnect the UCH connectors.

Remove the UCH after removing its three mounting bolts (C).



IMPORTANT: remember to replace the protective plastic cover when refitting.

OPERATION

When the engine immobiliser system is operational (approximately **10 seconds** after the ignition is switched off), the red engine immobiliser tell-tale light flashes (slow flashing, one illumination/second).

After switching on the ignition, the antenna/transponder ring analyses the key code and sends it to the decoder unit or the UCH (depending on equipment).

If the code is recognised by the decoder unit or by the UCH (depending on equipment) it sends a code to the injection computer or to the coded solenoid valve via a coded connection and extinguishes the red engine immobiliser tell-tale light (after approximately **3 seconds**).

At this precise moment, several things may happen:

- The injection computer or coded solenoid valve (depending on equipment) has no reference code in its memory:
 - the code sent to it is inscribed in its memory.

- The injection computer or coded solenoid valve (depending on equipment) has a reference code in its memory:
 - The code sent to it is compared with its reference code.
 - If the two codes match, the computer unlocks the injection or the coded solenoid valve (depending on equipment) and authorises engine starting. When the ignition is switched on, the injection warning light (petrol or direct injection diesel if equipped) and the red engine immobiliser tell-tale light illuminate for a few seconds and extinguish, thereby indicating that the system is operating correctly.
 - If the two codes do not match, the system remains locked to prevent the engine being started. When the ignition is switched on, the injection warning light (petrol or direct injection diesel if equipped) illuminates for a few seconds and extinguishes whilst the red engine immobiliser tell-tale light flashes (rapid flashing). Vehicle starting is not authorised.

NOTE: in order for the system to operate correctly, there must be no objects (example: key rings) placed between the key and the antenna / transponder ring.

IMPORTANT: when the battery has a low charge, the drop in voltage caused by the attempt to activate the starter motor may re-activate the engine immobiliser. If the voltage is too low, it is impossible to start the vehicle, even by pushing.

REPLACING, REALLOCATING OR ADDING ONE OR MORE KEY HEADS (without replacing the decoder unit)

Vehicle with decoder unit (without Plips)

Only the keys present when this procedure is carried out will be operational, on condition:

- that they have already been coded for this vehicle,
- that they are new (uncoded).

NOTE: to de-allocate a key, simply do not have it present when carrying out this operation.

- **Procedure using the XR25**

XR25 connected (fiche n° 38, code D38):

1. Check that the decoder unit is correctly coded. Bargraph **19 RH side** should be extinguished.

IMPORTANT: the maximum time between carrying out each operation is three minutes, otherwise the procedure is cancelled (returns to original configuration).

2. With the ignition switched off, enter the secret after sales code (eight numbers) as indicated below:

- enter **G41***, "?" is shown on the display,
- enter the first three figures and validate with *, "?" is shown on the display,
- enter the next two figures and validate with *, "?" is shown on the display,
- enter the last three figures and validate with *, "**LEC**" is shown on the display,
- the code appears on the display in three sequences, then "?" is shown on the display:

- If the code displayed is correct, validate with *, **Pro** and **bon** are shown on the display, bargraph **19 LH side** illuminates (the immobiliser tell-tale light extinguishes).
- If the code displayed is incorrect, enter "**G**" and restart the procedure for entering the code.

3. Enter # **58**:

- Switch on the ignition using one of the keys to be allocated:
 - if the key is accepted, bargraph **18 LH side** illuminates, the red tell-tale light flashes rapidly and the display on the XR25 indicates "**1**" (# **58**),
 - if the key is not accepted, bargraph **18 LH side** does not illuminate (# **58 = 0**); in this case, restart the procedure or try again with another key.

NOTE: in the event that the same key is tried twice, the system ignores it (the value # **58** does not change), the engine immobiliser tell-tale light remains extinguished and bargraphs **11** and **12 RH side** illuminate.

- Switch on the ignition using the other key or keys to be allocated (maximum of four) if they are available. Important: they must be old keys for the vehicle or new keys which are uncoded (# **58** indicates the number of keys allocated).

IMPORTANT: in the event that some of the keys are not available, a reallocation procedure will have to be carried out afterwards with all the keys.

4. Switch off the ignition, validate the allocation using command mode **G81***, **Pro** and **fin** are shown on the display. Bargraphs **18** and **19 LH side** extinguish. The red engine immobiliser tell-tale light flashes, the keys are operational. The procedure is complete.

NOTE: it is possible to cancel the key reallocation procedure during the procedure itself by entering command mode **G80*** with the ignition switched off (returns to the original configuration).

- **Procedure using the NXR or OPTIMA tools**

NXR or OPTIMA 5800 connected.

1. Choose the "**Fault finding**" menu.
2. Select and validate the vehicle type (Mégane).
3. Select and validate the system on which fault finding is to be carried out:
 - **Engine immobiliser** for vehicles with decoder unit (without PLIP),
 - **Connection unit** for vehicles with UCH (with PLIP).

4. Choose the "**Status**" menu and check whether the decoder unit is correctly coded. The bar-graph for the "**Key programming not carried out**" line should be extinguished.

5. Choose the "**Command**" menu.

IMPORTANT: the maximum time between each operation is three minutes, otherwise the procedure is cancelled (returns to original configuration).

6. Select and validate the "**Computer configuration**" function and validate line **41** "**Introducing the secret code**".

With the ignition switched off, enter the secret after sales code (eight figures) and validate it.

- If the code displayed is correct, "**OK**" is displayed on the screen.
 - If the code displayed is incorrect, "**Fail**" is displayed on the screen.
Then choose the "**Ignore**" menu and restart the procedure for entering the code.
7. Select the "**Parameters**" menu ; line **58** will show the number of keys allocated.

NOTE: if the fault finding tool is equipped with an update which is earlier than version 03, carry out point 7 of the procedure, ignoring the number of keys allocated, as indicated on line 58 of the "**Parameters**" menu.

The number of keys allocated will only be displayed after point **8** has been carried out.

- Switch on the ignition using one of the keys to be allocated:
 - if the key is accepted, the red tell-tale light flashes rapidly and line **58** indicates "**1**",
 - if the key is not accepted, the red tell-tale light remains extinguished and line **58** indicates "**0**". In this case, restart the procedure or try again with another key.

NOTE: in the event that the same key is used twice, the system ignores it (the value of line **58** does not change) and the engine immobiliser tell-tale light remains extinguished.

- Switch the ignition on for a few seconds using the vehicle key or keys to be allocated (maximum of four) if they are available.

IMPORTANT: these must be the old keys for the vehicle or new uncoded keys. Line **58** indicates the number of keys allocated.

IMPORTANT: in the event that some of the keys are not available, a reallocation procedure will have to be carried out afterwards with all the keys.

8. Switch off the ignition and validate the allocation of keys:
 - choose the "**Command**" menu,
 - select and validate the "**Computer configuration**" function,
 - select and validate line **81**.

If the procedure is successful, "**OK**" is displayed on the screen.

The red engine immobiliser tell-tale light flashes, the keys are operational.
The procedure is complete.

NOTE: it is possible to cancel the key reallocation procedure during the procedure itself, after selecting and validating line **80** of the "**Command**" menu, "**Computer configuration**" function with the ignition switched off (returns to original configuration).

Vehicle with UCH (with Plips)

Only the keys present during this procedure will be operational, on condition:

- that they were already coded for this vehicle,
- that they are new (uncoded).

• Procedure using the XR25

XR25 connected (fiche n° 64, side 2/2, code D45):

1. Check that the UCH is correctly coded. Bargraph **16 RH side** should be extinguished.

IMPORTANT: the maximum time between carrying out each operation is three minutes, otherwise the procedure is cancelled (returns to the original configuration).

2. Ignition off, enter the secret after sales code (eight figures) as indicated below:
 - enter **G41***, "?" is shown on the display,
 - enter the first three figures and validate with *, "?" is shown on the display,
 - enter the next two figures and validate with *, "?" is shown on the display,
 - enter the last three figures and validate with *, "**LEC**" is shown on the display,
 - the code appears on the display in three sequences, then "?" is shown on the display:
 - If the code displayed is correct, validate with *, **Pro** and **bon** are shown on the display, bargraph **17 LH side** illuminates (the engine immobiliser tell-tale light extinguishes).
 - If the code displayed is incorrect, enter "**G**" and restart the procedure for entering the code.

3. Enter # **58** :

- Switch on the ignition using one of the keys to be allocated:
 - if the key is accepted, bargraph **16 LH side** illuminates, the red tell-tale light flashes rapidly and the display on the XR25 indicates "**1**" (# **58**),
 - if the key is not accepted, bargraph **16 LH side** does not illuminate (# **58 = 0**); in this case, restart the procedure or try again with another key.

NOTE: in the event that the same key is used twice, the system ignores it (the value of line 58 does not change) and the engine immobiliser tell-tale light remains extinguished and bargraphs **14 LH side** and **RH side** illuminate.

- Switch on the ignition using the other vehicle key or keys to be allocated (maximum of four) if available.

IMPORTANT: these must be the old keys for the vehicle or new uncoded keys (# **58** indicates the number of keys allocated).

IMPORTANT: in the event that some of the keys are not available, a reallocation procedure will have to be carried out afterwards with all the keys.

4. Switch off the ignition, validate the allocation using command mode **G81***, **Pro** and **fin** are shown on the display. Bargraphs **16** and **17 LH side** extinguish. The red engine immobiliser tell-tale light flashes, the keys are operational. The procedure is complete.

NOTE: it is possible to cancel the key reallocation procedure during the procedure itself by entering command mode **G80***, ignition on (returns to the original configuration).

• Procedure using the NXR or OPTIMA

The method is the same as for the version with decoder unit. Follow the same procedure.

Special features of PLIPs (depending on equipment)

In order for the radio frequency PLIPs to work, it may be necessary to resynchronise them after having allocated the keys.

Press on the PLIP for more than **10 seconds** (until the red tell-tale light on the key extinguishes), then press it again three times.

REPLACING A DECODER UNIT ONLY (depending on equipment) VEHICLE WITHOUT PLIPS

To carry out this procedure you must have at least one of the old keys for the vehicle.

- **Procedure using the XR25**

XR25 connected (fiche n° 38, code D38):

1. Check that the new decoder unit is not coded. Bargraph **19 RH side** should be illuminated.

IMPORTANT: the maximum time between carrying out each operation is three minutes, otherwise the procedure is cancelled (returns to the original configuration).

2. Ignition off, enter the secret after sales code (eight figures) as indicated below:
 - enter **G41***, "?" is shown on the display,
 - enter the first three figures and validate with *, "?" is shown on the display,
 - enter the next two figures and validate with *, "?" is shown on the display,
 - enter the last three figures and validate with *, "**LEC**" is shown on the display,
 - the code appears on the display in three sequences, then "?" is shown on the display:
 - If the code displayed is correct, validate with *, **Pro** and **fin** are shown on the display, bargraph **19 LH side** illuminates.
 - If the code displayed is not correct, enter "**G**" and restart the procedure for entering the code.

3. Switch on the ignition (**one of the old keys for the vehicle must be used**):
 - if the code is correct, bargraph **18 LH side** illuminates, the red tell-tale light flashes rapidly (# **58 = 1**), bargraphs **11, 12 and 13 RH side** illuminate,
 - if the code is incorrect, bargraph **18 LH side** does not illuminate; in this case, restart the procedure.

NOTE: if the key is not coded, bargraph **18 LH side** does not illuminate; restart the procedure **using an old key for the vehicle**.

4. Switch on the ignition using the other vehicle key or keys to be allocated (maximum of four) if available.

IMPORTANT: these must be the old keys for the vehicle or new uncoded keys (# **58** indicates the number of keys allocated).

IMPORTANT :

In the event that some of the keys are not available, a reallocation procedure will have to be carried out afterwards with all the keys.

5. Switch off the ignition, validate the procedure using mode **G81***, the red engine immobiliser tell-tale light should flash. Bargraphs **18, 19 LH side** and **19 RH side** extinguish.

NOTE: it is possible to cancel the key reallocation procedure during the procedure itself by entering command mode **G80***, ignition on (returns to the original configuration).

6. Check the engine configuration:
 - petrol or direct injection diesel vehicle, bargraph **3 RH side** should be extinguished,
 - diesel vehicle with coded solenoid valve, bargraph **3 RH side** should be illuminated.

Changing the configuration:

- petrol or direct injection diesel vehicle, enter command mode **G22*1***,
- diesel vehicle with coded solenoid valve, enter command mode **G22*2***.

7. The procedure is complete.

- **Procedure using the NXR or OPTIMA**

NXR or OPTIMA 5800 connected:

1. Choose the "**Fault finding**" menu.
2. Select and validate the vehicle type (Mégane).
3. Select and validate the system on which fault finding is to be carried out:
 - **Engine immobiliser** for vehicles with decoder unit (without PLIP).
 - **Connection unit** for vehicles with UCH (with PLIP).

4. Choose the "**Status**" menu and check that the decoder unit is not coded. The bargraph for the "**Programming not carried out**" line should be illuminated.

5. Choose the "**Command**" menu.

IMPORTANT: there should be a maximum of three minutes between carrying out each operation, otherwise the procedure is cancelled (returns to the original configuration).

6. Select and validate the "**Computer configuration**" function and validate line 41 "**Entering the secret code**".

Ignition off, enter the secret after sales code (eight figures) and validate it.

- If the code displayed is correct, "**OK**" is displayed on the screen.
 - If the code displayed is incorrect, "**Fail**" is displayed on the screen.
Then choose the "**Ignore**" menu and restart the procedure for entering the code.
7. Select the "**Parameters**" menu; line 58 will show the number of keys allocated:

NOTE: if the fault finding tool has an update which is earlier than version 03, carry out point 7 of the procedure, ignoring the number of keys allocated as indicated on line 58 of the "**Parameters**" menu.
The number of keys allocated will only be visible after point 8 has been carried out.

- Switch on the ignition (**one of the old keys for the vehicle must be used**):

- if the code is correct, the bargraph for line 18 on the "**Status**" menu illuminates, the red tell-tale light flashes rapidly and line 58 indicates "1",
- if the code is incorrect, the bargraph for line 18 on the "**Status**" menu remains extinguished, the red tell-tale light remains extinguished and line 58 indicates "0". In this case, restart the procedure.

NOTE: if the key is not coded, the bargraph for line 18 on the "**Status**" menu does not illuminate. Restart the procedure using an old key for the vehicle.

- Switch on the ignition using the other vehicle key or keys to be allocated (maximum of 4) if they are available.

IMPORTANT: these must be the old keys for the vehicle or new uncoded keys. Line 58 indicates the number of keys allocated.

IMPORTANT: in the event that some of the keys are not available, a reallocation procedure will have to be carried out afterwards with all the keys.

8. Switch off the ignition and validate the key allocation:

- choose the "**Command**" menu,
- select and validate the "**Computer configuration**" function,
- select and validate line 81.

The red engine immobiliser tell-tale light flashes, the keys are operational.

NOTE: it is possible to cancel the key reallocation procedure during the procedure itself, after selecting and validating line 80 of the "**Command**" menu, "**Computer configuration**" function, ignition off (returns to the original configuration).

9. Check the engine configuration:
- Petrol or direct injection diesel vehicle, the bargraph for the "**Coded diesel solenoid valve configuration**" line on the "**Status**" menu should be extinguished.
 - Diesel vehicle with coded solenoid valve, the bargraph for the "**Coded diesel solenoid valve configuration**" line on the "**Status**" menu should be illuminated.

Changing the configuration

After choosing the "**Command**" menu, select and validate the "**Computer configuration**" function:

- Select the "**Petrol engine configuration**" line for petrol or direct injection diesel vehicles.
- Select the "**Diesel engine configuration**" line for diesel vehicles with coded solenoid valve.

10. The procedure is complete.

REPLACING A UCH ONLY (depending on equipment) VEHICLE WITH PLIPS

To carry out this procedure you must have at least one of the old keys for the vehicle.

- **Procedure using the XR25**

XR25 connected (fiche n° 64, side 2/2, code **D45**):

1. Check that the new **UCH** is not coded. Bargraph **16 RH side** should be illuminated.

IMPORTANT: there should be a maximum of three minutes between carrying out each operation, otherwise the procedure is cancelled (returns to the original configuration).

2. Ignition off, enter the secret after sales code (eight figures) as indicated below:
 - enter **G41***, "?" is shown on the display,
 - enter the first three figures and validate with *, "?" is shown on the display,
 - enter the next two figures and validate with *, "?" is shown on the display,
 - enter the last three figures and validate with *, "**LEC**" is shown on the display,
 - the code appears on the display in three sequences, then "?" is shown on the display:
 - If the code displayed is correct, validate with *, **Pro** and **fin** are shown on the display, bargraph **17 LH side** illuminates.
 - If the code displayed is not correct, enter "**G**" and restart the procedure for entering the code.
3. Switch on the ignition (**one of the old keys for the vehicle must be used**):
 - if the code is correct, bargraph **16 LH side** illuminates, the red tell-tale light flashes rapidly (# **58 = 1**), bargraphs **14 LH side** and **RH side** and **15 RH side** illuminate,
 - if the code is incorrect, bargraph **16 LH side** does not illuminate; in this case, restart the procedure.

NOTE: if the key is not coded, bargraph **16 LH side** does not illuminate; restart the procedure using an old key for the vehicle.

4. Switch on the ignition using the other vehicle key or keys to be allocated (maximum of four) if they are available.

IMPORTANT: these must be the old keys for the vehicle or new uncoded keys (# 58 indicates the number of keys allocated).

IMPORTANT: in the event that none of the keys are available, a reallocation procedure will have to be carried out afterwards with all the keys.

5. Switch off the ignition, validate the procedure using mode **G81***, the red engine immobiliser tell-tale light should flash. Bargraphs **16 LH side** and **RH side** and **17 LH side** extinguish.

NOTE: it is possible to cancel the key reallocation procedure during the procedure itself by entering command mode **G80***, ignition on (returns to the original configuration).

6. Check the engine configuration:
 - Petrol or direct injection diesel vehicle, bargraph **19 RH side** side 2/2 should be extinguished.
 - Diesel vehicle with coded solenoid valve, bargraph **19 RH side** side 2/2 should be illuminated.

Changing the configuration:

- Petrol or direct injection diesel vehicle, enter command mode **G25*1***.
- Diesel vehicle with coded solenoid valve, enter command mode **G25*2***.

7. Enter command mode **G60*** to lock the programming into the system in order to obtain correct operation of the functions managed by the UCH. Bargraph **17 RH side** should illuminate.

NOTE: for other UCH configurations (depending on vehicle equipment) see the UCH Technical Note.

8. The procedure is complete.

• Procedure using the NXR and OPTIMA

NXR or OPTIMA 5800 connected.

1. Choose the "**Fault finding**" menu.
2. Select and validate the vehicle type (Mégane).
3. Select and validate the system on which fault finding is to be carried out:
 - **Engine immobiliser** for vehicles with decoder unit (without PLIP).
 - **Connection unit** for vehicles with UCH (with PLIP).
4. Choose the "**Status**" menu and check that the decoder unit is not coded. The bargraph for the "**Key programming not carried out**" line should be illuminated.
5. Choose the "**Command**" menu.

IMPORTANT: there should be a maximum of three minutes between carrying out each operation, otherwise the procedure is cancelled (returns to the original configuration).

6. Select and validate the "**Computer configuration**" function and validate line **41 "Entering the secret code"**.

Ignition off, enter the secret after sales code (eight figures) and validate it.

- If the code displayed is correct, "**OK**" is displayed on the screen.
- If the code displayed is incorrect, "**Fail**" is displayed on the screen. Then choose the "**Ignore**" menu and restart the procedure for entering the code.

7. Select the "**Parameters**" menu; line **58** will show the number of keys allocated :

NOTE: if the fault finding tool has an update which is earlier than version **03**, carry out point **7** of the procedure, ignoring the number of keys allocated as indicated on line **58** of the "**Parameters**" menu.

The number of keys allocated will only be visible after point **8** has been carried out.

- Switch on the ignition (**one of the old keys for the vehicle must be used**) :
 - if the code is correct, the bargraph for line **18** on the "**Status**" menu illuminates, the red tell-tale light flashes rapidly and line **58** indicates "**1**",
 - if the code is incorrect, the bargraph for line **18** on the "**Status**" menu remains extinguished, the red tell-tale light remains extinguished and line **58** indicates "**0**". In this case, restart the procedure.

NOTE: if the key is not coded, the bargraph for line **18** on the "**Status**" menu does not illuminate. Restart the procedure using an old key for the vehicle.

- Switch on the ignition using the other vehicle key or keys to be allocated (maximum of 4) if available.

IMPORTANT: these must be the old keys for the vehicle or new uncoded keys. Line **58** indicates the number of keys allocated.

IMPORTANT: in the event that some of the keys are not available, a reallocation procedure will have to be carried out afterwards with all the keys.

8. Switch off the ignition and validate the key allocation:

- Choose the "**Command**" menu.
- Select and validate the "**Computer configuration**" function.
- Select and validate line **81**.
The red engine immobiliser tell-tale light flashes, the keys are operational.

NOTE: it is possible to cancel the key reallocation procedure during the procedure itself after selecting and validating line **80** of the "**Command**" menu, "**Computer configuration**" function, ignition off (returns to the original configuration).

9. Check the engine configuration:
- Petrol or direct injection diesel vehicle, the bargraph for the "**Coded diesel solenoid valve configuration**" line on the "**Status**" menu should be extinguished.
 - Diesel vehicle with coded solenoid valve, the bargraph for the "**Coded diesel solenoid valve configuration**" line on the "**Status**" menu should be illuminated.

Changing the configuration

After choosing the "**Command**" menu, select and validate the "**Computer configuration**" function:

- Select the "**Petrol engine configuration**" line for petrol or direct injection diesel vehicles.
- Select the "**Diesel engine configuration**" line for diesel vehicles with coded solenoid valve.

10. Lock the programming into the system by selecting and validating line **60** in order to obtain correct operation of the functions managed by the UCH.

NOTE: for other UCH configurations (depending on vehicle equipment) see the UCH Technical Note.

11. The procedure is complete.

Special features of PLIPs

In order for the radio frequency PLIPs to work, it may be necessary to resynchronise them after having allocated the keys.

Press on the PLIP for more than **10 seconds** (until the red tell-tale light on the key extinguishes), then press it again three times.

REPLACING THE INJECTION COMPUTER (petrol and direct injection diesel vehicle)

The injection computer is supplied uncoded. It will therefore have to be programmed with the engine immobiliser system code when it is fitted so that vehicle starting can be authorised.

IMPORTANT: vehicles equipped with the **F9Q** engine have a special injection computer which will only operate if it is coded.

Simply carry out the following operations:

- use the coded key for the vehicle to switch the ignition on for a few minutes without starting the engine,
- switch off the ignition, the engine immobiliser function will be ensured approximately **10 seconds** afterwards (the red engine immobiliser tell-tale light flashes).

NOTE: it is possible to check starting prevention:

- Using the **XR25**
- **Vehicle with decoder unit** = fiche 38, code **D38**.
- **Vehicle with UCH** = fiche 64 side 2/2, code **D45**.

Switch off the ignition, wait until the red tell-tale light starts to flash slowly.

Enter command:

- **G04*** for vehicles equipped with a decoder unit,
- **G29*** for vehicles equipped with a UCH.

Ignition still switched off (bargraph "**Forced protection mode**" illuminates).

Switch on the ignition and check that it is not possible to start the vehicle and that the tell-tale light flashes (rapid flashing).

- Using the **NXR** or **OPTIMA**

NXR or **OPTIMA 5800** connected.

1. Choose the "**Fault finding**" menu.
2. Select and validate the vehicle type (Mégane).
3. Select and validate the system on which fault finding is to be carried out:
 - **Engine immobiliser** for vehicles with decoder unit (without PLIP).
 - **Connection unit** for vehicles with UCH (with PLIP).
4. Choose the "**Command**" menu, then select and validate the "**Actuator command**" function.
5. Select and validate the "**Forced protection mode command**" line.

Switch on the ignition and check that it is not possible to start the vehicle and that the tell-tale light flashes (rapid flashing).

CHECKING

In injection fault finding, it is possible to determine the status of the computer.

IMPORTANT: this verification process is not operational on all computers.

Using the XR25

Connect the **XR25** to the vehicle and enter the code corresponding to the type of injection (ignition on).

- If the injection computer is not coded, bargraph **2 RH side** (engine immobiliser) should be illuminated and after entering ***22, "2def"** should be shown on the XR25 display. Cassette No. 15 needs to be used for this test.
- If the injection computer is coded and there is no fault on the coded line, bargraph **2 RH side** should be extinguished and after entering ***22, "bon"** should appear on the XR25 display (even if the computer coding does not correspond to the vehicle).

NOTE: if the injection computer finds a fault on the coded line, **"1def"** will appear on the **XR25** display after entering ***22** (bargraph **2 RH side** should illuminate). In this case, repair it and erase the fault by disconnecting the battery.

Using the NXR or OPTIMA

NXR or OPTIMA 5800 connected.

1. Choose the **"Fault finding"** menu.
2. Select and validate the vehicle type (Mégane).
3. Select and validate the system on which fault finding is to be carried out (injection).
4. Select the **"Fault"** menu and check that everything is correct:
 - if the computer is not coded, the message **"Code not programmed"** is displayed in this menu,
 - if the computer is coded and no fault appears, the message **"Fault not tested by the computer"** is displayed in this menu.

IMPORTANT

With this engine immobiliser system, the vehicle retains its engine immobiliser code for life.

In addition, the system no longer has a security code.

For this reason, testing using computers borrowed from the store which must then be returned or used on another vehicle is prohibited.

They can no longer be decoded.

REPLACING THE CODED SOLENOID VALVE ELECTRONIC UNIT (diesel except direct injection)

For the operation to remove/refit the screening which gives access to the coded solenoid valve and the electrical solenoid, see the Technical Notes corresponding to the vehicle generation (**N.T. 2568A, 2990A**, etc.).

The electronic unit of the solenoid valve is supplied uncoded. It will therefore be necessary to programme it with the engine immobiliser system code when it is fitted in order to authorise vehicle starting.

Simply carry out the following operations:


- use the coded key for the vehicle to switch the ignition on for a few seconds without starting the engine,
- switch off the ignition, the engine immobiliser function will be ensured approximately **10 seconds** afterwards (the engine immobiliser tell-tale light flashes).

ENGINE IMMOBILISER

Coded key

82


DECODER UNIT CONNECTIONS (vehicle without PLIP)



15456R

Track	Allocation
1	Antenna/transponder ring - decoder unit connection
3	Diagnostic socket information (line L)
4	Coded information to the injection computer or electronic unit of the coded solenoid valve
5	Red engine immobiliser tell-tale light
7	+ After ignition feed
9	+ Before ignition feed
10	Antenna/transponder ring - decoder unit connection
12	Diagnostic socket information (line K)
14	Antenna/transponder ring - decoder unit connection
15	Earth
17	Antenna/transponder ring - decoder unit connection

PASSENGER COMPARTMENT CONTROL UNIT CONNECTIONS (UCH) (vehicle with PLIP)



15451R

Only the tracks used for the engine immobiliser system are described below (for the others, refer to the "UCH" Technical Note).

1 track black connector (PP5)

Track	Allocation
1	+ Before ignition feed

8 track black connector (PP1)

Track	Allocation
1	Earth
3	+ After ignition feed
4	Earth

15 track grey connector (PE4)

Track	Allocation
7	Diagnostic socket information (line K)

30 track grey connector (PE3)

Track	Allocation
2	Transponder ring/UCH connection
3	Transponder ring/UCH connection
16	Coded information to the injection computer or electronic unit of the coded solenoid valve
20	Red engine immobiliser tell-tale light
22	Transponder ring/UCH connection
26	Transponder ring/UCH connection
29	Diagnostic socket information (line L)


ENGINE IMMOBILISER

Coded key

82


WIRING DIAGRAM

Vehicle equipped with a decoder unit (without PLIP)



15356R3

Vehicle equipped with a UCH (with PLIP)



15356R2

* The connection may or may not be present, depending on the vehicle (see the Wiring Diagrams).

COMPONENTS KEY

- 104** Ignition switch
- 120** Injection computer
- 225** Diagnostic socket
- 247** Injection warning light and engine immobiliser tell-tale light on the instrument panel
- 260** Passenger compartment fuse box
- 503** Decoder unit
- 645** Passenger Compartment Control Unit (UCH)
- 711** Coded solenoid valve (diesel except direct injection)

ENGINE IMMOBILISER

Coded key with PLIP

82

FAULT FINDING - INTRODUCTION

SETTING UP DIALOGUE BETWEEN THE XR25 AND THE DECODER UNIT

- Connect the XR25 to the diagnostic socket.
- Set the ISO selector to **S8**
- Enter **D45**

2.n64

Pay attention to the key head electronic unit and antenna/transponder ring part numbers.

ENGINE IMMOBILISER FAULT - INJECTION FICHE

- fiche n° 27 for F7R, F3R, K7M engines - BG 2 RH side
- fiche n° 28 for E7J engines - BG 2 RH side
- fiche n° 51 for F9Q engines - BG 15 LH side

ERASING THE MEMORY

After repairing the engine immobiliser system, enter G0** on the XR25 keyboard to erase the memorised fault.

ENGINE IMMOBILISER

Coded key with PLIP

82

PRESENTATION OF XR25 FICHE N° 64 SIDE 1/2

		S8		D 4 5		64		
1	<input type="checkbox"/>	ILLUM. EXTING.	→ CORRECT SIDE OF FICHE → TURN FICHE OVER	CODE PRESENT		<input type="checkbox"/>		
2								
3								
4								
5								
6								
7								
8								
9								
10	<input type="checkbox"/>	+ AFTER IGN.						
PASS. COMP. CONTROL UNIT (FAULTS - STATUS) to read side 2/2 : G 02 * Erase fault memory : G 0 **								
11	<input type="checkbox"/>	LOCKING (press locking button for 3secs)		UNLOCKING		<input type="checkbox"/>		
12	<input type="checkbox"/>	HEATED WINDSCREEN		REAR DEMISTER		<input type="checkbox"/>		
13				REAR SCREEN WIPE		<input type="checkbox"/>		
14	<input type="checkbox"/>	REAR SCREEN WASH	ACTION ON BUTTONS	FR SCREEN WASH		<input type="checkbox"/>		
15	<input type="checkbox"/>	RAISE	Driver's window	LOWER		<input type="checkbox"/>		
16	<input type="checkbox"/>	SIDE		DIPPED		<input type="checkbox"/>		
17	<input type="checkbox"/>	REVERSE GEAR	ACTION ON LIGHT SWITCH	MAIN		<input type="checkbox"/>		
18	<input type="checkbox"/>	LH INDICATOR		RH INDICATOR		<input type="checkbox"/>		
19	<input type="checkbox"/>	HAZARD						
20				OIL PRESSURE (mm) engine running		<input type="checkbox"/>		

ANG

FI218641

vrf6408.0

ENGINE IMMOBILISER

Coded key with PLIP

82


PRESENTATION OF XR25 FICHE N° 64 SIDE 2/2

2n64											
1	<table style="width: 100%; border: none;"> <tr> <td style="border: 1px solid black; padding: 2px;"></td> <td style="border: none; padding: 2px;">EXTING.</td> <td style="border: none; padding: 2px;">→ CORRECT SIDE OF FICHE</td> <td style="border: none; padding: 2px;">CODE PRESENT</td> <td style="border: 1px solid black; padding: 2px;"></td> </tr> <tr> <td style="border: 1px solid black; padding: 2px;"></td> <td style="border: none; padding: 2px;">ILLUM.</td> <td style="border: none; padding: 2px;">→ TURN FICHE OVER</td> <td colspan="2"></td> </tr> </table>		EXTING.	→ CORRECT SIDE OF FICHE	CODE PRESENT			ILLUM.	→ TURN FICHE OVER		
	EXTING.	→ CORRECT SIDE OF FICHE	CODE PRESENT								
	ILLUM.	→ TURN FICHE OVER									
2	<table style="width: 100%; border: none;"> <tr> <td style="border: 1px solid black; padding: 2px;"></td> <td style="border: none; padding: 2px;">STOP</td> <td style="border: none; padding: 2px;">STALK POSITION</td> <td style="border: none; padding: 2px;">FRONT SCREEN</td> <td style="border: 1px solid black; padding: 2px;"></td> </tr> <tr> <td colspan="2"></td> <td style="border: none; padding: 2px;">(depending on equip.)</td> <td style="border: none; padding: 2px;">WIPE PARK</td> <td style="border: 1px solid black; padding: 2px;"></td> </tr> </table>		STOP	STALK POSITION	FRONT SCREEN				(depending on equip.)	WIPE PARK	
	STOP	STALK POSITION	FRONT SCREEN								
		(depending on equip.)	WIPE PARK								
3	<table style="width: 100%; border: none;"> <tr> <td style="border: 1px solid black; padding: 2px;"></td> <td style="border: none; padding: 2px;">SLOW SPEED</td> <td colspan="3"></td> </tr> <tr> <td colspan="2"></td> <td style="border: none; padding: 2px;">FAST SPEED</td> <td style="border: 1px solid black; padding: 2px;"></td> <td></td> </tr> </table>		SLOW SPEED						FAST SPEED		
	SLOW SPEED										
		FAST SPEED									
4	<table style="width: 100%; border: none;"> <tr> <td style="border: 1px solid black; padding: 2px;"></td> <td style="border: none; padding: 2px;">← FRONT DOOR OPEN</td> <td style="border: none; padding: 2px;">→</td> <td style="border: none; padding: 2px;">FRONT OR REAR DOOR OPEN (or boot)</td> <td style="border: 1px solid black; padding: 2px;"></td> </tr> <tr> <td colspan="2"></td> <td style="border: none; padding: 2px;">→</td> <td colspan="2"></td> </tr> </table>		← FRONT DOOR OPEN	→	FRONT OR REAR DOOR OPEN (or boot)				→		
	← FRONT DOOR OPEN	→	FRONT OR REAR DOOR OPEN (or boot)								
		→									
5	<table style="width: 100%; border: none;"> <tr> <td colspan="2"></td> <td style="border: none; padding: 2px;">DOORS</td> <td style="border: none; padding: 2px;">BOOT MODULE</td> <td style="border: 1px solid black; padding: 2px;"></td> </tr> </table>			DOORS	BOOT MODULE						
		DOORS	BOOT MODULE								
6											
7											
8											
9											
10											
PASS. COMP. CONTROL UNIT (key radio freq.) to read side 1/2 : G 01 *											
11	<table style="width: 100%; border: none;"> <tr> <td style="border: 1px solid black; padding: 2px;"></td> <td style="border: none; padding: 2px;">KEY (RF) VALIDATED</td> <td style="border: none; padding: 2px;">RADIO FREQ. COMMAND</td> <td style="border: none; padding: 2px;">SOURCE LAST DOOR SWITCH : KEY (RF)</td> <td style="border: 1px solid black; padding: 2px;"></td> </tr> </table>		KEY (RF) VALIDATED	RADIO FREQ. COMMAND	SOURCE LAST DOOR SWITCH : KEY (RF)						
	KEY (RF) VALIDATED	RADIO FREQ. COMMAND	SOURCE LAST DOOR SWITCH : KEY (RF)								
12	<table style="width: 100%; border: none;"> <tr> <td style="border: 1px solid black; padding: 2px;"></td> <td style="border: none; padding: 2px;">NO TRANSMITTER (RF) PROGRAMMED</td> <td colspan="3"></td> </tr> <tr> <td colspan="2"></td> <td style="border: none; padding: 2px;">SYNCHRO (RF) IN PROGRESS</td> <td style="border: 1px solid black; padding: 2px;"></td> <td></td> </tr> </table>		NO TRANSMITTER (RF) PROGRAMMED						SYNCHRO (RF) IN PROGRESS		
	NO TRANSMITTER (RF) PROGRAMMED										
		SYNCHRO (RF) IN PROGRESS									
13	<table style="width: 100%; border: none;"> <tr> <td style="border: 1px solid black; padding: 2px;"></td> <td style="border: none; padding: 2px;">IMMOBILISER ACTIVE</td> <td colspan="3"></td> </tr> <tr> <td colspan="2"></td> <td style="border: none; padding: 2px;">+ AFTER IGN</td> <td style="border: 1px solid black; padding: 2px;"></td> <td></td> </tr> </table>		IMMOBILISER ACTIVE						+ AFTER IGN		
	IMMOBILISER ACTIVE										
		+ AFTER IGN									
14	<table style="width: 100%; border: none;"> <tr> <td style="border: 1px solid black; padding: 2px;"></td> <td style="border: none; padding: 2px;">KEY PRESENT</td> <td colspan="3"></td> </tr> <tr> <td colspan="2"></td> <td style="border: none; padding: 2px;">KEY CODE RECVD</td> <td style="border: 1px solid black; padding: 2px;"></td> <td></td> </tr> </table>		KEY PRESENT						KEY CODE RECVD		
	KEY PRESENT										
		KEY CODE RECVD									
15	<table style="width: 100%; border: none;"> <tr> <td style="border: 1px solid black; padding: 2px;"></td> <td style="border: none; padding: 2px;">PROTECTED MODE ENFORCED</td> <td style="border: none; padding: 2px;">KEY</td> <td style="border: none; padding: 2px;">KEY CODE VALIDATED</td> <td style="border: 1px solid black; padding: 2px;"></td> </tr> </table>		PROTECTED MODE ENFORCED	KEY	KEY CODE VALIDATED						
	PROTECTED MODE ENFORCED	KEY	KEY CODE VALIDATED								
16	<table style="width: 100%; border: none;"> <tr> <td style="border: 1px solid black; padding: 2px;"></td> <td style="border: none; padding: 2px;">PROG. 1ST KEY</td> <td style="border: none; padding: 2px;">PROGRAMME KEY</td> <td style="border: none; padding: 2px;">PROG. NOT CARRIED OUT</td> <td style="border: 1px solid black; padding: 2px;"></td> </tr> </table>		PROG. 1ST KEY	PROGRAMME KEY	PROG. NOT CARRIED OUT						
	PROG. 1ST KEY	PROGRAMME KEY	PROG. NOT CARRIED OUT								
17	<table style="width: 100%; border: none;"> <tr> <td style="border: 1px solid black; padding: 2px;"></td> <td style="border: none; padding: 2px;">KEY PROG. OR RESYNCHRO. AUTHORISED</td> <td colspan="3"></td> </tr> <tr> <td colspan="2"></td> <td style="border: none; padding: 2px;">CALIBRATION ENDED</td> <td style="border: 1px solid black; padding: 2px;"></td> <td></td> </tr> </table>		KEY PROG. OR RESYNCHRO. AUTHORISED						CALIBRATION ENDED		
	KEY PROG. OR RESYNCHRO. AUTHORISED										
		CALIBRATION ENDED									
18	<table style="width: 100%; border: none;"> <tr> <td style="border: 1px solid black; padding: 2px;"></td> <td style="border: none; padding: 2px;">WITH RADIO FREQ. FUNCTION</td> <td colspan="3"></td> </tr> <tr> <td colspan="2"></td> <td style="border: none; padding: 2px;">OVERSPEED ARABIA</td> <td style="border: 1px solid black; padding: 2px;"></td> <td></td> </tr> </table>		WITH RADIO FREQ. FUNCTION						OVERSPEED ARABIA		
	WITH RADIO FREQ. FUNCTION										
		OVERSPEED ARABIA									
19	<table style="width: 100%; border: none;"> <tr> <td style="border: 1px solid black; padding: 2px;"></td> <td style="border: none; padding: 2px;">COURTESY LIGHT TIMER</td> <td style="border: none; padding: 2px;">CONFIGURATION (fixed display)</td> <td style="border: none; padding: 2px;">DIESEL WITH CODED SV</td> <td style="border: 1px solid black; padding: 2px;"></td> </tr> </table>		COURTESY LIGHT TIMER	CONFIGURATION (fixed display)	DIESEL WITH CODED SV						
	COURTESY LIGHT TIMER	CONFIGURATION (fixed display)	DIESEL WITH CODED SV								
20	<table style="width: 100%; border: none;"> <tr> <td colspan="3"></td> <td style="border: none; padding: 2px;">CABRIOLET E64</td> <td style="border: 1px solid black; padding: 2px;"></td> </tr> </table>				CABRIOLET E64						
			CABRIOLET E64								
ANG											


FI218642


vrf6408.0

REPRESENTATION OF BARGRAPHS

-  Illuminates when dialogue is established with the product computer, if it remains extinguished:
- the code does not exist,
 - there is a line, XR25 or computer fault.

REPRESENTATION OF FAULTS (always on coloured background)








-  Illuminated, indicates a fault on the product tested, the associated text defines the fault.

-  Extinguished, indicates that no fault has been detected on the product tested.



REPRESENTATION OF STATUS (always on white background)

Engine stopped, ignition on, no operator action

The status bargraphs on the fiche are represented in the condition they should be in when the engine is stopped, ignition on, no operator action.

- If on the fiche, the bargraph is shown  the XR25 should give as information 
 - If on the fiche, the bargraph is shown  the XR25 should give as information 
 - If on the fiche, the bargraph is shown  the XR25 should give as information
- either  or 

Engine running


-  Extinguished when the function or condition specified on the fiche is no longer being met.
-  Illuminated when the function or condition specified on the fiche is being met.

ENGINE IMMOBILISER

Coded key with PLIP

82

FAULT FINDING - INTERPRETATION OF XR25 BARGRAPHS

6 	Bargraph 6 LH side illuminated <u>DIESEL SOLENOID VALVE CLEARANCE</u>	Fiche n° 64
--	---	-------------

NOTES	None
--------------	------

Check that the coded solenoid valve is correctly fed (12 V and earth).

Repair the wiring.

Set the XR25 to pulse detection mode (**key G**, entered on the Vin terminal) and check for pulses on **track 16 of UCH connector PE3**.

Are there pulses?

NO	Replace the passenger compartment control unit.
----	---

YES	Replace the coded solenoid valve.
-----	-----------------------------------

AFTER REPAIR	Erase the memorised fault by entering G0** on the XR25 keyboard. Carry out a conformity check. Check that the engine immobiliser system operates correctly.
---------------------	---


vrf6408.0

ENGINE IMMOBILISER

Coded key with PLIP

82

FAULT FINDING - INTERPRETATION OF XR25 BARGRAPHS

6 	Bargraph 6 RH side illuminated <u>CODED LINE CIRCUIT</u> XR25 aid: CC.1 CO.0	Fiche n° 64
---	--	-------------

NOTES	None
--------------	------

Check that UCH connector PE3 is correctly connected.

Check the continuity and insulation from earth and 12V of the wiring between **track 16 of UCH connector PE3** and **injection computer track ***, depending on the engine.

Repair the wiring if necessary.

XR25 in pulse detection mode (key **G**, entered on the **Vin** terminal), and check for pulses on **track 16 of UCH connector PE3**.

Are there pulses?

NO	Replace the passenger compartment control unit.
----	---

YES	Replace the injection computer.
-----	---------------------------------

Tracks * = 35 for F7R, F3R
 37 for K7M
 29 for E7J
 59 for F9Q

AFTER REPAIR	Erase the flashing fault memory using G0**. Carry out a conformity check.
---------------------	---


vrf6408.0

ENGINE IMMOBILISER

Coded key with PLIP

82

FAULT FINDING - INTERPRETATION OF XR25 BARGRAPHS

<p>6</p> 	<p>Bargraphs 6 LH side and RH side illuminated</p> <p><u>SIGNAL CLEARANCE VIA DIESEL SOLENOID VALVE AND CODED LINE</u></p>	<p>Fiche n° 64</p>
---	---	--------------------

NOTES	None
--------------	------

Check the condition of the wiring between:



and check the solenoid valve resistance values.

Repair the faulty wiring if necessary or if the resistance values are incorrect, replace the solenoid valve.

Set the XR25 to pulse detection mode (**key G**, entered on the Vin terminal) and check for pulses on **track 16 of UCH connector PE3**.

Are there pulses?

YES	Replace the coded solenoid valve.
-----	-----------------------------------

NO	<p>Solenoid valve connector connected and PE3 connector disconnected, check on the wiring side for 12 V on track 16 of connector PE3 when the ignition is switched on.</p> <p>Is there 12 V?</p> <p>YES Replace the passenger compartment control unit.</p> <p>NO Replace the coded solenoid valve.</p>
----	---


AFTER REPAIR	<p>Erase the flashing fault memory using G0**.</p> <p>Carry out a conformity check.</p>
---------------------	---

ENGINE IMMOBILISER

Coded key with PLIP

82

FAULT FINDING - INTERPRETATION OF XR25 BARGRAPHS

<p>7</p> 	<p>Bargraph 7 LH side illuminated Fiche n° 64</p> <p><u>RADIO FREQUENCY KEY DESYNCHRONISED</u></p> <p>XR25 aid: *07 = 1.deF 2.deF</p>
---	--

<p>NOTES</p>	<p>None.</p>
---------------------	--------------

See the key resynchronisation procedure.

<p>AFTER REPAIR</p>	<p>Erase the memorised fault using G0**. Switch off the ignition and check whether the engine immobiliser tell-tale light flashes.</p>
----------------------------	--


vrf6408.0

ENGINE IMMOBILISER

Coded key with PLIP

82

FAULT FINDING - INTERPRETATION OF XR25 BARGRAPHS

7 	Bargraph 7 RH side illuminated <u>RADIO FREQUENCY KEY NOT RECOGNISED</u>	Fiche n° 64
---	--	-------------

NOTES	None.
--------------	-------

Can the vehicle be started using this key?

YES	The key is incorrectly coded. Replace the key.
-----	--

NO	The key is incorrectly allocated. See the key allocation procedure.
----	---

AFTER REPAIR	Erase the memorised fault using G0**. Switch off the ignition and check whether the engine immobiliser tell-tale light flashes.
---------------------	--


vrf6408.0

ENGINE IMMOBILISER

Coded key with PLIP

82

FAULT FINDING - INTERPRETATION OF XR25 BARGRAPHS

<p>8</p> 	<p>Bargraph 8 RH side illuminated <u>BATTERY / BATTERIES LOW / FLAT</u></p> <p>Fiche n° 64</p>
---	---

<p>NOTES</p>	<p>None.</p>
---------------------	--------------

Replace the battery and if the key still does not operate, resynchronise the key.

<p>AFTER REPAIR</p>	<p>Erase the memorised fault using G0**. Switch off the ignition and check whether the engine immobiliser tell-tale light flashes.</p>
----------------------------	--


vrf6408.0

ENGINE IMMOBILISER

Coded key with PLIP

82

FAULT FINDING - INTERPRETATION OF XR25 BARGRAPHS

<p>9</p> 	<p>Bargraph 9 LH side illuminated</p> <p style="text-align: right;">Fiche n° 64</p> <p><u>ANTENNA/TRANSPONDER RING RESPONSE</u></p> <p>XR25 aid: *09 = bon deF CC.0 CO.1</p>
---	--

NOTES	None.
--------------	-------

deF	Replace the antenna/transponder ring.
------------	---------------------------------------

CC.0	Repair the wiring between track 3 of UCH connector PE3 and track 4 of the antenna/transponder ring.
-------------	--

CO.1	<p>Check the condition of the wiring between tracks 3 and 26 of connector PE3 and tracks 4 and 5 of the antenna/transponder ring.</p> <p>Repair if necessary.</p> <hr/> <p>XR25 in pulse detection mode (key G, entered on the Vin terminal), check for pulses on track 4 of the antenna/transponder ring connector.</p> <p>Are there pulses?</p> <p>NO Replace the antenna/transponder ring.</p> <p>YES Replace the passenger compartment control unit.</p>
-------------	--


AFTER REPAIR	<p>Erase the memorised fault using G0**.</p> <p>Switch off the ignition and check whether the engine immobiliser tell-tale light flashes.</p>
---------------------	---

ENGINE IMMOBILISER

Coded key with PLIP

82

FAULT FINDING - INTERPRETATION OF XR25 BARGRAPHS

9 	Bargraph 9 RH side illuminated <u>KEY INTERROGATION</u> XR25 aid: *39 = CC.1 CO.0	Fiche n° 64
---	---	-------------

NOTES	None.
--------------	-------

XR25 in pulse detection mode (key G, entered on the Vin terminal), check for pulses on **tracks 2 and 22 of UCH connector PE3** when the ignition is switched on (connectors connected).

Are there pulses?

NO	Replace the passenger compartment control unit.
----	---

YES	Replace the antenna/transponder ring.
-----	---------------------------------------

AFTER REPAIR	Erase the memorised fault using G0**. Switch off the ignition and check whether the engine immobiliser tell-tale light flashes.
---------------------	---


vrf6408.0

ENGINE IMMOBILISER

Coded key with PLIP

82

FAULT FINDING - INTERPRETATION OF XR25 BARGRAPHS

<p>14, 15</p> 	<p>Bargraphs 14 LH side and 15 RH side extinguished when the ignition is switched on</p> <p><u>KEY INTERROGATION CIRCUIT</u></p>	<p>Fiche n° 64</p>
--	---	--------------------

NOTES	<p>None.</p>
--------------	--------------

Try with the second key.
Does a bargraph illuminate?

YES	<p>Replace the key (see the procedure for replacing the key).</p>
-----	---

NO	<p>Check the continuity of the wiring between:</p> <table style="margin-left: auto; margin-right: auto;"> <tr> <td style="text-align: center;">UCH connector PE3</td> <td style="text-align: center;"> $\left\{ \begin{array}{l} 22 \rightarrow 2 \\ 26 \rightarrow 5 \\ 3 \rightarrow 4 \\ 2 \rightarrow 3 \end{array} \right\}$ </td> <td style="text-align: center;">} antenna/transponder ring</td> </tr> </table> <p>Is the wiring in good condition?</p>	UCH connector PE3	$\left\{ \begin{array}{l} 22 \rightarrow 2 \\ 26 \rightarrow 5 \\ 3 \rightarrow 4 \\ 2 \rightarrow 3 \end{array} \right\}$	} antenna/transponder ring
UCH connector PE3	$\left\{ \begin{array}{l} 22 \rightarrow 2 \\ 26 \rightarrow 5 \\ 3 \rightarrow 4 \\ 2 \rightarrow 3 \end{array} \right\}$	} antenna/transponder ring		

NO	<p>Repair the faulty wiring.</p>
----	----------------------------------

YES	<p>Check for pulses on track 22 of UCH connector PE3 each time the ignition is switched on. Are there pulses?</p> <p>YES Replace the passenger compartment control unit.</p> <p>YES Replace the antenna/transponder ring.</p>
-----	--


AFTER REPAIR	<p>Erase the memorised fault using G0**. Switch off the ignition and check whether the engine immobiliser tell-tale light flashes.</p>
---------------------	--

ENGINE IMMOBILISER

Coded key with PLIP

82

FAULT FINDING - INTERPRETATION OF XR25 BARGRAPHS

<p>14</p>  <p>15</p>	<p>Bargraphs 14 LH side and 14 RH side illuminated, 15 RH side extinguished when the ignition is switched on</p> <p><u>KEY INTERROGATION CIRCUIT</u></p> <p>Fiche n° 64</p>
--	---

<p>NOTES</p>	<p>None</p>
---------------------	-------------

Perhaps the key belongs to another vehicle or is not allocated to this vehicle.
See the key allocation procedure.

If the fault persists, replace the key.

<p>AFTER REPAIR</p>	<p>Erase the memorised fault using G0**. Switch off the ignition and check whether the engine immobiliser tell-tale light flashes.</p>
----------------------------	--

vrf6408.0

ENGINE IMMOBILISER

Coded key with PLIP

82

FAULT FINDING - CUSTOMER COMPLAINTS (petrol version)

NOTES	Only consult these customer complaints after a complete check using the XR25.
--------------	---

WHEN THE IGNITION IS SWITCHED ON, THE INJECTION WARNING LIGHT FLASHES PERMANENTLY, REMAINS ILLUMINATED OR NEVER ILLUMINATES OR THE VEHICLE DOES NOT START Chart 1

WHEN DRIVING (deceleration) AND AT IDLE SPEED, THE INJECTION WARNING LIGHT FLASHES PERMANENTLY Chart 2

WHEN THE IGNITION IS SWITCHED ON, THE ENGINE IMMOBILISER TELL-TALE LIGHT REMAINS ILLUMINATED FOR MORE THAN 3 SECONDS OR NEVER ILLUMINATES Chart 3

ENGINE IMMOBILISER TELL-TALE LIGHT FLASHES PERMANENTLY Chart 4

RADIO FREQUENCY PLIP DOES NOT OPERATE (doors + luggage compartment will no longer lock or unlock) Chart 5


ENGINE IMMOBILISER

Coded key with PLIP

82

FAULT FINDING - FAULT CHARTS (petrol version or direct injection diesel)

Chart 1	WHEN THE IGNITION IS SWITCHED ON, THE INJECTION WARNING LIGHT FLASHES PERMANENTLY, REMAINS ILLUMINATED OR NEVER ILLUMINATES OR THE VEHICLE DOES NOT START (the engine immobiliser tell-tale light functions normally)
NOTES	On fiche n° 64 side 2/2, if BG 6 RH is illuminated, see the section on dealing with the bargraph.




Tracks * = 35 for F7R, F3R engines 29 for E7J engines
 37 for K7M engines 59 for F9Q engines

AFTER REPAIR	Carry out a conformity check. Check that the engine immobiliser system operates correctly. Erase the faults using G0**.
---------------------	---

vrf6408.0

FAULT FINDING - FAULT CHARTS (petrol version or direct injection diesel)

Chart 2	WHEN DRIVING (deceleration) AND AT IDLE SPEED, THE INJECTION WARNING LIGHT FLASHES PERMANENTLY
NOTES	None



Tracks * = 35 for F7R, F3R engines 29 for E7J engines
 37 for K7M engines 59 for F9Q engines

AFTER REPAIR	Carry out a conformity check. Check that the engine immobiliser system operates correctly.
---------------------	---


ENGINE IMMOBILISER

Coded key with PLIP

82

FAULT FINDING - FAULT CHARTS (petrol version or direct injection diesel)

Chart 3	WHEN THE IGNITION IS SWITCHED ON THE ENGINE IMMOBILISER TELL-TALE LIGHT REMAINS ILLUMINATED OR NEVER ILLUMINATES
NOTES	None




AFTER REPAIR	Carry out a conformity check. Check that the engine immobiliser system operates correctly.
---------------------	---

FAULT FINDING - FAULT CHARTS

Chart 4	ENGINE IMMOBILISER TELL-TALE LIGHT FLASHES PERMANENTLY
----------------	---

NOTES	None
--------------	------



AFTER REPAIR	Carry out a conformity check. Check that the engine immobiliser system operates correctly. Erase the faults using G0**.
---------------------	---


ENGINE IMMOBILISER

Coded key with PLIP

82

FAULT FINDING - FAULT CHARTS (all versions)

Chart 5	RADIO FREQUENCY PLIP DOES NOT OPERATE (doors + luggage compartment will not lock or unlock)
NOTES	If the vehicle does not start, check the engine immobiliser as the radio frequency does not manage this.



NOTE : If the second key is not available, use the key from another Mégane and check whether BG 7 RH side illuminates.
 If it illuminates, there is a fault with the key.
 If it does not illuminate, replace the passenger compartment control unit.

AFTER REPAIR	Carry out a conformity check. Check that the engine immobiliser system operates correctly. Erase the faults using G0**.
---------------------	---

vrf6408.0

ENGINE IMMOBILISER

Coded key with PLIP

82

FAULT FINDING - CUSTOMER COMPLAINTS (diesel version)

NOTES	Only consult these customer complaints after a complete check using the XR25.
--------------	---

WHEN THE IGNITION IS SWITCHED ON, THE ENGINE IMMOBILISER TELL-TALE LIGHT ILLUMINATES FOR 3 SECONDS, EXTINGUISHES THEN REMAINS ILLUMINATED UNTIL THE IGNITION IS SWITCHED OFF (it may or may not be possible to start the vehicle) Chart 1

WHEN THE IGNITION IS SWITCHED ON, THE ENGINE IMMOBILISER TELL-TALE LIGHT ILLUMINATES FOR 3 SECONDS, THEN EXTINGUISHES BUT THE VEHICLE CANNOT BE STARTED Chart 2

WHEN THE IGNITION IS SWITCHED ON, THE ENGINE IMMOBILISER TELL-TALE LIGHT REMAINS ILLUMINATED FOR MORE THAN 3 SECONDS OR NEVER ILLUMINATES Chart 3

ENGINE IMMOBILISER TELL-TALE LIGHT FLASHES PERMANENTLY Chart 4

THE RADIO FREQUENCY PLIP DOES NOT OPERATE (doors + luggage compartment will no longer lock or unlock) Chart 5

ENGINE IMMOBILISER


Coded key with PLIP

82

FAULT FINDING - FAULT CHARTS

Chart 1	WHEN THE IGNITION IS SWITCHED ON, THE ENGINE IMMOBILISER TELL-TALE LIGHT ILLUMINATES FOR 3 SECONDS, EXTINGUISHES THEN REMAINS ILLUMINATED UNTIL THE IGNITION IS SWITCHED OFF
----------------	---

NOTES	BG 6 LH side should be extinguished
--------------	-------------------------------------



AFTER REPAIR	Carry out a conformity check. Check that the engine immobiliser system operates correctly. Erase the faults using G0**.
---------------------	---

vrf6408.0


ENGINE IMMOBILISER

Coded key with PLIP

82

FAULT FINDING - FAULT CHARTS

Chart 2	WHEN THE IGNITION IS SWITCHED ON, THE ENGINE IMMOBILISER TELL-TALE LIGHT ILLUMINATES FOR 3 SECONDS, THEN EXTINGUISHES, BUT THE VEHICLE CANNOT BE STARTED
NOTES	BG 6 LH side should be extinguished



AFTER REPAIR	Carry out a conformity check. Check that the engine immobiliser system operates correctly. Erase the faults using G0**.
---------------------	---

vrf6408.0


ENGINE IMMOBILISER

Coded key with PLIP

82

FAULT FINDING - FAULT CHARTS

Chart 3	THE ENGINE IMMOBILISER TELL-TALE LIGHT REMAINS PERMANENTLY ILLUMINATED OR PERMANENTLY EXTINGUISHED
NOTES	None



AFTER REPAIR	Carry out a conformity check. Check that the engine immobiliser system operates correctly. Erase the faults using G0**.
---------------------	---

vrf6408.0


ENGINE IMMOBILISER

Coded key with PLIP

82

FAULT FINDING - FAULT CHARTS

Chart 4	ENGINE IMMOBILISER TELL-TALE LIGHT FLASHES PERMANENTLY
NOTES	None



AFTER REPAIR	Carry out a conformity check. Check that the engine immobiliser system operates correctly. Erase the faults using G0**.
---------------------	---


ENGINE IMMOBILISER

Coded key with PLIP

82

FAULT FINDING - FAULT CHARTS (all versions)

Chart 5	RADIO FREQUENCY PLIP DOES NOT OPERATE (doors + luggage compartment will not lock or unlock)
NOTES	If the vehicle does not start, check the engine immobiliser as the radio frequency does not manage this.



NOTE : If the second key is not available, use the key from another Mégane and check whether BG 7 RH side illuminates.
 If it illuminates, there is a fault with the key.
 If it does not illuminate, replace the passenger compartment control unit.

AFTER REPAIR	Carry out a conformity check. Check that the engine immobiliser system operates correctly. Erase the faults using G0**.
---------------------	---

vrf6408.0








ENGINE IMMOBILISER

Coded key with PLIP

82

FAULT FINDING - CHECKING CONFORMITY

NOTES	If a fault bargraph illuminates, refer to the corresponding fault chart.
--------------	--

Order of operations	Function to be checked	Action	Bargraph	Display and notes
1	XR25 dialogue	D 45		2.n64
2			1 	<ul style="list-style-type: none"> - Extinguished : fiche on the correct side - Illuminated : turn the fiche over
3			1 	Code present
4	Front door open Front or rear door (luggage compartment) open		4 	Illuminated if doors are open
5	Luggage compartment module		5 	
6	Engine immobiliser status		13 	Illuminated if engine immobiliser is active
7	Receipt of key present, key code received and key code valid information		14  15 	Illuminated when the key is present, key code received and recognised





ENGINE IMMOBILISER

Coded key with PLIP

82

FAULT FINDING - CHECKING CONFORMITY

NOTES	If a fault bargraph illuminates, refer to the corresponding fault chart.
--------------	--

Order of operations	Function to be checked	Action	Bargraph	Display and notes
8	Forced protection mode		15 	Illuminated only after command G04* entered on the XR25 (ignition off, engine immobiliser active).
9	Receipt of 1 st key programming information		16 	Illuminated if 1 st key programming carried out.
10	Programming not carried out		16 	Illuminated if programming not carried out.
11	Programming or key reallocation authorised		17 	Illuminated if programming or reallocation of keys in progress.

ADDITIONAL CHECKS

LIST OF VARIOUS

- # 09 Antenna / transponder ring feed fault
- # 35 Key status details valid
- # 38 Vehicle locked automatically
- # 58 Number of keys programmed (4 maximum)
- # 70 Number of radio frequency keys memorised
- # 77 Key presented is not blank

COMMAND MODES G--*

To use this function, enter G on the XR25 keyboard, then the number of the chosen command followed by a star.

- 01 Coded solenoid valve test mode.
- 02 Engine immobiliser tell-tale light flashing.
- 03 Engine immobiliser tell-tale light illuminated.
- 04 Forced protection mode: activates the engine immobiliser function even if the key is correct, which allows starting prevention to be checked. Bargraph 9 LH side should illuminate.
This command must be entered when the ignition is switched off even though the engine immobiliser is active.
Important: switching off the ignition cancels this command.
- 13 End of fault finding.
- 25 Configuration :
 - G 25 * 1 * = petrol or direct injection diesel configuration .
 - G 25 * 2 * = diesel with coded solenoid valve configuration.
- 41 Enter after sales code
- 47 *0* De-configure courtesy lights
1 Configure courtesy lights
- 50 *0* De-configure automatic door locking
1 Configure automatic door locking
- 55 *0* De-configure cabriolet
1 Configure cabriolet
- 57 *0* De-configure overspeed warning (Arabia)
1 Configure overspeed warning (Arabia)
- 64 Authorisation of blank key / blank decoder
- 65 Prohibition of blank key / blank decoder
- 70 Reading of Part Number
- 80 Abandon key reallocation mode
- 81 Validate key reallocation mode

ENGINE IMMOBILISER

Coded key without PLIP

82

FAULT FINDING - INTRODUCTION

SETTING UP DIALOGUE BETWEEN THE XR25 AND THE DECODER UNIT

- Connect the XR25 to the diagnostic socket.
- Set the ISO selector to **S8**
- Enter **D38**

2.cle

Pay attention to the key head electronic unit and antenna/ transponder ring part numbers.

ENGINE IMMOBILISER FAULT - INJECTION FICHE

- fiche n° 27 for F7R, F3R, K7M engines - BG 2 RH side
- fiche n° 28 for E7J engines - BG 2 RH side
- fiche n° 51 for F9Q engines - BG 15 LH side

ERASING THE MEMORY

After repairing the engine immobiliser system, enter G0** on the XR25 keyboard to erase the memorised fault.

ENGINE IMMOBILISER

Coded key without PLIP

82

PRESENTATION OF XR25 FICHE N° 38

N°38	S8	code : D 3 8	read : XcLE	
1		CODE PRESENT	<input type="checkbox"/>	
2	<input checked="" type="checkbox"/> ENG. IMMOB. 1	COMPUTER CONFIGURATION (FIXED DISPLAY)	ENG. IMMOB. 2 <input type="checkbox"/>	
3			CODED DIESEL SOLENOID (SOL) <input type="checkbox"/>	
4	<input checked="" type="checkbox"/> WARN. LIGHT OPERATION (LED) ENG. IMMOB. 1 ONLY			
5	<input checked="" type="checkbox"/> + APC PRESENT		FEED : RING (cc earth) OR RING RESPONSE <input type="checkbox"/>	
6	<input checked="" type="checkbox"/> DIESEL SOL. ACQUITTAL	FAULTS	CODED LINE * 26 <input type="checkbox"/>	
7	<input checked="" type="checkbox"/> KEY INTERROGATION		LED WARN LIGHT * 27 <input type="checkbox"/>	
8	<input type="checkbox"/> SOL. TEST MODE SET		PROTECT MODE SET <input type="checkbox"/>	
9	<input type="checkbox"/> IF <input checked="" type="checkbox"/> TEST <input type="checkbox"/> IF <input type="checkbox"/> NO TEST	→	RE-READ DIESEL SOL. ACKNOWLEDGE <input type="checkbox"/>	
10	<input type="checkbox"/> ACTIVE ENG. IMMOB.		CODED LINE REREAD FAULT <input type="checkbox"/>	
If : X = 1 (key not coded)		If : X = 2 (key coded)		
ENG. IMMOB. (KEY)				
Erase memory : G 0 ** End of test : G 13 *				
11		KEY PRESENT	<input type="checkbox"/>	
12	KEY CODE	→ RECEIVED	<input type="checkbox"/>	
13		→ VALIDATED	<input type="checkbox"/>	
14				
15				
16				
17	<input checked="" type="checkbox"/> "MANUAL MODE" BUTTON PRESSED		BUTTON DEFECT <input type="checkbox"/>	
18	<input type="checkbox"/> VALIDATING FIRST KEY			
19	<input type="checkbox"/> VALIDATION AUTHORISED		VALIDATION NOT PERFORMED <input type="checkbox"/>	
20			XR25 MEMORY <input type="checkbox"/>	
SEE REPAIR MANUEL				18 ANG

CONTROL MODES : G...*

01 Diesel sol. mechanical check only if line 3 RH and line 5 RH / LH

Test: Switch off ignition, enter: G01*
Switch on ignition again. Valve will open and shut for 30 secs (listen to check).


Part No. : G70 *

90 Fiche identification


FI21838


v6408.0

REPRESENTATION OF BARGRAPHS

-  Illuminates when dialogue is established with the product computer, if it remains extinguished:
- the code does not exist,
 - there is a line, XR25 or computer fault.

REPRESENTATION OF FAULTS (always on coloured background)








-  Illuminated, indicates a fault on the product tested, the associated text defines the fault.

-  Extinguished, indicates that no fault is detected on the product tested.



REPRESENTATION OF STATUS (always on white background)

Engine stopped, ignition on, no operator action

The status bargraphs on the fiche are represented in the condition they should be in when the engine is stopped, the ignition on and there is no operator action.

- If on the fiche the bargraph is shown  the XR25 should give as information 
 - If on the fiche the bargraph is shown  the XR25 should give as information 
 - If on the fiche the bargraph is shown  the XR25 should give as information
- either  or 

Engine running


-  Extinguished when the function or condition specified on the fiche is no longer being met.
-  Illuminated when the function or condition specified on the fiche is being met.

ENGINE IMMOBILISER

Coded key without PLIP

82

FAULT FINDING - INTERPRETATION OF XR25 BARGRAPHS

<p>3</p> 	<p>Bargraph 3 RH side</p> <p><u>DECODER UNIT CONFIGURATION</u></p> <p>Fiche n° 38</p>
---	--

<p>NOTES</p>	<p>BG 3 RH side extinguished : petrol or diesel injection configuration BG 3 RH side illuminated : diesel coded solenoid valve configuration</p>
---------------------	--

Reconfigure the decoder unit correctly using the XR25.

Command **G22*** **1* injection**
 2* diesel coded solenoid valve

<p>AFTER REPAIR</p>	<p>Check that the configuration for the decoder unit is correct.</p>
----------------------------	--


v6408.0

ENGINE IMMOBILISER

Coded key without PLIP

82

FAULT FINDING - INTERPRETATION OF XR25 BARGRAPHS

5 	Bargraph 5 LH side remains extinguished, ignition on <u>+ AFTER IGNITION FEED CIRCUIT</u> XR25 aid: no + after ignition feed	Fiche n° 38
---	---	-------------

NOTES	Check the condition of the battery
--------------	------------------------------------

Check the condition of the wiring between **track 7 of the decoder unit and the + after ignition feed fuse**.
Repair if necessary.

Ignition on, check for **12V on track 7 of the decoder unit**.

Is there 12 V?

NO	See the fault finding for the relay fuse unit.
----	--

YES	Replace the decoder unit.
-----	---------------------------

AFTER REPAIR	Erase the memorised fault by entering G0** on the XR25 keyboard. Carry out a conformity check. Check that the engine immobiliser system operates correctly.
---------------------	---


v6408.0

ENGINE IMMOBILISER

Coded key without PLIP

82

FAULT FINDING - INTERPRETATION OF XR25 BARGRAPHS

<p>5</p> 	<p>Bargraph 5 RH side illuminated Fiche n° 38</p> <p><u>ANTENNA/TRANSPONDER RING RESPONSE</u></p> <p>XR25 aid: *25 : deF CC.0 CO.1</p>
---	---

NOTES	None.
--------------	-------

deF	Replace the antenna/transponder ring.
------------	---------------------------------------

CC.0	Repair the wiring between track 1 of the decoder unit and track 4 of the antenna/transponder ring.
-------------	---

CO.1	<p>Check the condition of the wiring between:</p> <div style="text-align: center; margin: 10px 0;"> <table style="border: none;"> <tr> <td style="padding-right: 10px;">decoder unit</td> <td style="font-size: 2em; padding: 0 10px;">{</td> <td style="padding: 0 10px;"> <table style="border: none; margin: 0 auto;"> <tr> <td style="padding: 0 5px;">1</td> <td style="padding: 0 5px;">→</td> <td style="padding: 0 5px;">4</td> </tr> <tr> <td style="padding: 0 5px;">14</td> <td style="padding: 0 5px;">→</td> <td style="padding: 0 5px;">5</td> </tr> </table> </td> <td style="font-size: 2em; padding: 0 10px;">}</td> <td style="padding-left: 10px;">antenna/transponder ring</td> </tr> </table> </div> <p>Repair if necessary.</p> <p>Set the XR25 to pulse detection mode (key G, entered on the Vin terminal) and check for pulses on track 4 on the antenna/transponder ring (connectors connected). Are there pulses?</p> <p>YES Replace the decoder unit.</p> <p>NO Replace the antenna/transponder ring.</p>	decoder unit	{	<table style="border: none; margin: 0 auto;"> <tr> <td style="padding: 0 5px;">1</td> <td style="padding: 0 5px;">→</td> <td style="padding: 0 5px;">4</td> </tr> <tr> <td style="padding: 0 5px;">14</td> <td style="padding: 0 5px;">→</td> <td style="padding: 0 5px;">5</td> </tr> </table>	1	→	4	14	→	5	}	antenna/transponder ring
decoder unit	{	<table style="border: none; margin: 0 auto;"> <tr> <td style="padding: 0 5px;">1</td> <td style="padding: 0 5px;">→</td> <td style="padding: 0 5px;">4</td> </tr> <tr> <td style="padding: 0 5px;">14</td> <td style="padding: 0 5px;">→</td> <td style="padding: 0 5px;">5</td> </tr> </table>	1	→	4	14	→	5	}	antenna/transponder ring		
1	→	4										
14	→	5										

AFTER REPAIR	<p>Erase the memorised fault by entering G0** on the XR25 keyboard. Carry out a conformity check. Check that the engine immobiliser system operates correctly.</p>
---------------------	--


v6408.0

ENGINE IMMOBILISER

Coded key without PLIP


82

FAULT FINDING - INTERPRETATION OF XR25 BARGRAPHS

<p>7</p> 	<p>Bargraph 7 LH side illuminated</p> <p><u>KEY INTERROGATION CIRCUIT (CC)</u></p> <p>XR25 aid: *07 = CO CC.1</p>	<p>Fiche n° 38</p>
---	--	--------------------

NOTES	None.
--------------	-------

Check the condition of the wiring between:



Repair the faulty wiring.

With the XR25 in pulse detection mode (key **G**, entered on the **Vin** terminal), check for pulses on **tracks 10 and 17 of the decoder unit** when the ignition is switched on (decoder and ring connectors connected).

Are there pulses?

NO	Replace the decoder unit.
----	---------------------------

YES	Replace the antenna/transponder ring.
-----	---------------------------------------

AFTER REPAIR	<p>Erase the flashing fault memory using G0**.</p> <p>Switch off the ignition and check whether the engine immobiliser tell-tale light is flashing.</p>
---------------------	---



v6408.0

ENGINE IMMOBILISER

Coded key without PLIP

82

FAULT FINDING - INTERPRETATION OF XR25 BARGRAPHS

11-12 	Bargraphs 11 RH side and 12 RH side illuminated, 13 RH side extinguished when the ignition is switched on <u>KEY INTERROGATION CIRCUIT</u> XR25 aid: # 33 = 00 or 01 or 10	Fiche n° 38
13 		

NOTES	<p>If BG 5 RH side is illuminated, deal with BG 5 RH side. If BG 7 LH side is illuminated, deal with BG 7 LH side. # 09 = antenna/transponder ring feed fault. Wait until the engine immobiliser tell-tale light flashes before carrying out another test.</p>
--------------	--

33 = 00

This key belongs to another vehicle or it has not been allocated to this vehicle.
See the key allocation procedure.

33 = 01

The key used is not allocated to the vehicle.
See the key allocation procedure.

33 = 10

Change the key.

AFTER REPAIR	<p>Erase the memorised fault by entering G0** on the XR25 keyboard. Carry out a conformity check. Check that the engine immobiliser system operates correctly.</p>
---------------------	--

v6408.0

ENGINE IMMOBILISER

Coded key without PLIP

82

FAULT FINDING - CUSTOMER COMPLAINTS (petrol version)

NOTES	Only consult these customer complaints after a complete check using the XR25.
--------------	---

WHEN THE IGNITION IS SWITCHED ON, THE INJECTION WARNING LIGHT FLASHES PERMANENTLY, REMAINS ILLUMINATED OR NEVER ILLUMINATES OR THE VEHICLE DOES NOT START **Chart 1**

WHEN DRIVING (deceleration) AND AT IDLE SPEED, THE INJECTION WARNING LIGHT FLASHES PERMANENTLY **Chart 2**

WHEN THE IGNITION IS SWITCHED ON, THE ENGINE IMMOBILISER TELL-TALE LIGHT REMAINS ILLUMINATED FOR MORE THAN 3 SECONDS OR NEVER ILLUMINATES **Chart 3**

THE ENGINE IMMOBILISER TELL-TALE LIGHT FLASHES CONTINUOUSLY **Chart 4**

ENGINE IMMOBILISER


Coded key without PLIP

82

FAULT FINDING - FAULT CHARTS (petrol or direct injection diesel version)

Chart 1	WHEN THE IGNITION IS SWITCHED ON, THE INJECTION WARNING LIGHT FLASHES PERMANENTLY, REMAINS ILLUMINATED OR NEVER ILLUMINATES OR THE VEHICLE DOES NOT START (engine immobiliser tell-tale light functions normally)
----------------	--

NOTES	If bargraph 6 RH and 10 RH are illuminated, refer to how to deal with the bargraphs. Check that bargraph 19 RH is extinguished and that there are no problems with the injection system.
--------------	--



Tracks * = 35 for F3P, F3R engines 29 for E7J engines
 37 for K7M engines 59 for F9Q engines

AFTER REPAIR	Carry out a conformity check. Check that the engine immobiliser system operates correctly. Erase the faults using G0**.
---------------------	---

ENGINE IMMOBILISER


Coded key without PLIP

82

FAULT FINDING - FAULT CHARTS (petrol or direct injection diesel version)

Chart 2	WHEN DRIVING (deceleration) AND AT IDLE SPEED, THE INJECTION WARNING LIGHT FLASHES PERMANENTLY
----------------	---

NOTES	None.
--------------	-------



Tracks * = 35 for F3P, F3R engines 29 for E7J engines
37 for K7M engines 59 for F9Q engines

AFTER REPAIR	Carry out a conformity check. Check that the engine immobiliser system operates correctly.
---------------------	---

v6408.0


ENGINE IMMOBILISER

Coded key without PLIP

82

FAULT FINDING - FAULT CHARTS (petrol or direct injection diesel version)

Chart 3	WHEN THE IGNITION IS SWITCHED ON THE ENGINE IMMOBILISER TELL-TALE LIGHT REMAINS ILLUMINATED OR NEVER ILLUMINATES
NOTES	<p>Check that the configuration for the decoder unit is correct.</p> <p>Injection configuration : bargraph 3 RH extinguished.</p>



AFTER REPAIR	<p>Carry out a conformity check.</p> <p>Check that the engine immobiliser system operates correctly.</p>
---------------------	--

v6408.0


ENGINE IMMOBILISER

Coded key without PLIP

82

FAULT FINDING - FAULT CHARTS (petrol or diesel injection version)

Chart 4	THE ENGINE IMMOBILISER TELL-TALE LIGHT FLASHES PERMANENTLY
NOTES	None



AFTER REPAIR	Carry out a conformity check. Check that the engine immobiliser system operates correctly. Erase the faults using G0**.
---------------------	---

v6408.0

ENGINE IMMOBILISER

Coded key without PLIP

82

FAULT FINDING - CUSTOMER COMPLAINTS (diesel version)

NOTES	Only consult these customer complaints after a complete check using the XR25.
--------------	---

WHEN THE IGNITION IS SWITCHED ON, THE ENGINE IMMOBILISER TELL-TALE LIGHT ILLUMINATES FOR 3 SECONDS, EXTINGUISHES, THEN REMAINS ILLUMINATED UNTIL THE IGNITION IS SWITCHED OFF (it may or may not be possible to start the vehicle)

Chart 1

WHEN THE IGNITION IS SWITCHED ON, THE ENGINE IMMOBILISER TELL-TALE LIGHT ILLUMINATES FOR 3 SECONDS, THEN EXTINGUISHES BUT THE VEHICLE DOES NOT START

Chart 2

WHEN THE IGNITION IS SWITCHED ON, THE ENGINE IMMOBILISER TELL-TALE LIGHT REMAINS ILLUMINATED FOR MORE THAN 3 SECONDS OR NEVER ILLUMINATES

Chart 3

THE ENGINE IMMOBILISER TELL-TALE LIGHT FLASHES PERMANENTLY

Chart 4


ENGINE IMMOBILISER

Coded key without PLIP

82

FAULT FINDING - FAULT CHARTS

Chart 1	WHEN THE IGNITION IS SWITCHED ON, THE ENGINE IMMOBILISER TELL-TALE LIGHT ILLUMINATES FOR 3 SECONDS, EXTINGUISHES, THEN REMAINS ILLUMINATED UNTIL THE IGNITION IS SWITCHED OFF
NOTES	BG 6 LH side, 6 RH side and 10 RH side should be extinguished.



AFTER REPAIR	Carry out a conformity check. Check that the engine immobiliser system operates correctly. Erase the faults using G0**.
---------------------	---

v6408.0

ENGINE IMMOBILISER


Coded key without PLIP

82

FAULT FINDING - FAULT CHARTS

Chart 2	WHEN THE IGNITION IS SWITCHED ON, THE ENGINE IMMOBILISER TELL-TALE LIGHT ILLUMINATES FOR 3 SECONDS, THEN EXTINGUISHES, BUT THE VEHICLE DOES NOT START
----------------	---

NOTES	BG 6 LH side, 6 RH, 10 RH and 19 RH should be extinguished
--------------	--



AFTER REPAIR	Carry out a conformity check. Check that the engine immobiliser system operates correctly. Erase the faults using G0**.
---------------------	---

v6408.0


ENGINE IMMOBILISER

Coded key without PLIP

82

FAULT FINDING - FAULT CHARTS

Chart 3	THE ENGINE IMMOBILISER TELL-TALE LIGHT REMAINS PERMANENTLY ILLUMINATED OR REMAINS PERMANENTLY EXTINGUISHED
NOTES	Bargraph 19 RH side should be extinguished.



AFTER REPAIR	Carry out a conformity check. Check that the engine immobiliser system operates correctly. Erase the faults using G0**.
---------------------	---

v6408.0

ENGINE IMMOBILISER


Coded key without PLIP

82

FAULT FINDING - FAULT CHARTS

Chart 4	THE ENGINE IMMOBILISER TELL-TALE LIGHT FLASHES PERMANENTLY
----------------	---

NOTES	None
--------------	------



AFTER REPAIR	Carry out a conformity check. Check that the engine immobiliser system operates correctly. Erase the faults using G0**.
---------------------	---

v6408.0





ENGINE IMMOBILISER

Coded key without PLIP

82

FAULT FINDING - CHECKING CONFORMITY

NOTES	If a fault bargraph illuminates, refer to the corresponding fault chart.
--------------	--

Order of operations	Function to be checked	Action	Bargraph	Display and notes
1	XR25 dialogue	D38 (selector on S8)		X.cle
2			<p style="text-align: center;">1</p> 	Code present
3	Decoder unit conformity	G70*		X X X Parts Department number displayed in 2 sequences.
4	Interpretation of normally illuminated bargraphs		<p style="text-align: center;">2</p>  <p style="text-align: center;">2</p> 	<p>Engine immobiliser 1</p> <p>Engine immobiliser 2</p>
5	Computer configured for Petrol / Diesel		<p style="text-align: center;">3</p> 	<p>Illuminated if configured for diesel vehicle with coded solenoid valve. Extinguished if configured for petrol or direct injection diesel vehicle.</p> <p>Command:</p> <ul style="list-style-type: none"> - G22*1* petrol configuration - G22*2* diesel configuration







ENGINE IMMOBILISER

Coded key without PLIP

82

FAULT FINDING - CHECKING CONFORMITY

NOTES	If a fault bargraph illuminates, refer to the corresponding fault chart.
--------------	--

Order of operations	Function to be checked	Action	Bargraph	Display and notes
6	Forced protection mode		8 	Illuminated only after entering command G04* on the XR25 (ignition off, engine immobiliser active). Impossible to start the vehicle while BG 8 LH side is illuminated.
7	Engine immobiliser status		10 	Allumé fixe si antidémarrage actif : couper le contact et attendre environ 10 secondes pour que BG 10G soit allumé fixe. Eteint si antidémarrage inactif.
8	Receipt of key present, key code received, key code valid information		11  12  13 	Illuminated when key is present, key code received and recognised.
9	Receipt of 1st key programming information		18 	Illuminated if programming of 1st key carried out.



ENGINE IMMOBILISER

Coded key without PLIP

82

FAULT FINDING - CHECKING CONFORMITY

NOTES	If a fault bargraph illuminates, refer to the corresponding fault chart.
--------------	--

Order of operations	Function to be checked	Action	Bargraph	Display and notes
10	Programming authorised		19 	Illuminated if programming or reallocation in progress.
11	Programming not carried out		19 	Illuminated if programming not carried out.

ADDITIONAL CHECKS

COMMAND MODES G--*

To use this function, enter G on the XR25 keyboard, then the number of the chosen command followed by a star.

- 01** Coded solenoid valve test mode.
- 02** Engine immobiliser tell-tale light flashing.
- 03** Engine immobiliser tell-tale light illuminated.
- 04** Forced protection mode: activates the engine immobiliser function even if the key is correct, which allows starting prevention to be checked. Bargraph 8 LH side should illuminate. This command must be entered when the ignition is switched off even though the engine immobiliser is active.
Important: switching off the ignition cancels this command.
- 13** End of fault finding.
- 22** Configuration :
 - **G 22 * 1 *** = petrol or direct injection diesel configuration (bargraph 3 RH side should be extinguished).
 - **G 22 * 2 *** = diesel with coded solenoid valve configuration (bargraph 3 RH side should be illuminated).
- 41** Enter After Sales code
- 64** Authorisation of blank key / blank decoder
- 65** Prohibition of blank key / blank decoder
- 70** Reading of Part Number
- 80** Abandon key reallocation mode
- 81** Validate key reallocation mode

ENGINE IMMOBILISER

Coded key without PLIP

82

ADDITIONAL CHECKS

LIST OF VARIOUS

- # 09 Antenna/transponder ring feed fault
- # 33 Details of key valid status
- # 58 Number of keys programmed (maximum of 4)
- # 77 Key presented not blank
- # 90 N° of fiche used